



TUPLA KUPLA

Ohje lamppujen vaihtoon

Tupla Kupla sisältää kolme E27-kantaista energiansäästölamppua; kaksi 20 watin lamppua ja yhden 23 watin lampun suuremmissa 'kuplista'. Palaneet lamput on suositeltavaa korvata saman valmistajan samantyyppisillä lamput, jotta valon väri on tasainen koko valaisimessa. Suositeltavia lamppuja ovat esimerkiksi Megaman Spiral ja Airam Longlife.

Irrota aina virtajohto pistorasiasta ennen valaisimen avaamista.

Kaada Tupla Kupla kyljelleen naarmuttamattomalle alustalle. Avaa pohjan neljä ruuvia. [1]

Vedä metallirunkoa varovasti ulos valaisimesta kunnes yletyt valaisimen sisälle.

Suuremmissa 'kuplassa' lamppua pitävä varsi on kiinnitetty kuvan 1 nuolen osoittamasta kohdasta tukirautaan sokalla. Vapauta varsi tästä tuesta.

Varsi on saranoitu juurestaan. Sarana on lukittu juurestaan pystyasentoon sokalla. Irrota sokka. [2]

Vedä metallirunko varoen ulos Tupla Kuplasta kääntämällä samanaikaisesti saranoitua vartta. [2 ja 3]




Vaihdettuasi palaneet lamput, asenna metallirunko takaisin Tupla Kuplaan seuraten ylläolevia ohjeita käänteisessä järjestyksessä.

Varo kiristämästä pohjan ruuveja liikaa, jotta kierteet muovissa eivät riko. [3]

Valmistaja:

Melaja Oy
+358 10 321 0940
info@melaja.fi

www.doublebubble.fi



DOUBLE BUBBLE

Instructions on installing and changing lamps

The Double Bubble is lighted with three E27 type energy saving (compact fluorescent) bulbs, two 20 watt bulbs and one 23 watt bulb in the larger of the 'bubbles'. When replacing a bulb, it is recommended to use the same brand and type of bulb as the other two are. This ensures uniform colour of light. Recommended lamps are for example Megaman Spiral and Airam Longlife.

Always disconnect the power cord from the wall socket before opening the Double Bubble.

To access the bulbs, turn the Double Bubble over to its side. Remove the four screws at the bottom. [1]

Carefully pull the metal structure out of the Double Bubble until you can reach into the lamp.

The arm holding the bulb in the larger 'bubble' is tied to a support with a pin. Free the arm from the support.

The arm is attached to the metal base with a hinged joint that is locked to position with a pin. Pull out the pin. [2]

Turn the arm held by the hinge so that the metal structure can be removed from inside the Double Bubble. [2 and 3]
Be careful not to stress the electric cord leading to the hinged arm.

Once the metal structure is out of the Double Bubble, you can replace the bulbs.

To install the arms back into the Double Bubble, follow the above instructions in reverse order.

Be careful not to tighten the screws holding the bottom plate too much as this might break the threads in the plastic.

The Double Bubble is manufactured in Finland by:

Melaja Ltd
+358 10 321 0940
info@melaja.fi

www.doublebubble.fi

